



Goff's Enterprises, Inc.

Manufacturers of the Original Goff Curtain Walls
1228 Hickory Street • Pewaukee, Wisconsin 53072
Phone 800-234-0337 • 262-691-4998 • Fax 262-691-3255
Email sales@goffscw.com • Web www.goffscurtainwalls.com

Installation Instructions for Retro-Fit Wind Ties*

Required tools: sharp awl, rivet gun, hammer drill w/ ¼" concrete bit

To attach wind tie to curtain:

1. Using awl, punch four evenly spaced holes in section of webbing to be attached to curtain (it may help to use a soft piece of wood as backing and tap awl with a hammer).
2. Holding webbing up to curtain in the desired position, mark four corresponding holes on the curtain. Punch through with awl, being careful not to ream them too wide.
3. Rivet wind tie to curtain with the rivet (provided) passing first through the webbing, then the curtain, then the washer (also provided). Make sure all four rivets are securely fastened.

To attach D-ring to ground:

1. Position D-ring so it will line up with wind tie when curtain is in place.
2. Mark the two holes on the ground, making sure they line up with the holes on the D-ring.
3. Remove D-ring from position and drill two ¼" holes as marked, making sure the holes are more than deep enough to accept concrete rivets (provided).
4. Put D-ring back into position and drop concrete rivets into holes, making sure that your holes are lined up well enough to allow rivets to enter fairly straight.
5. Before pounding directly on the expansion shaft of the concrete rivet, pound on the lip of the rivet to drive it all the way into the hole (it may help to rest a flat head screwdriver on the lip and tap it in). Seat both rivets.
6. Once rivets are seated into the D-ring, pound the shafts all the way in to set the rivets in the ground.
7. Flip up D-ring and connect webbing strap.

*Please note Goffs does not consider this to be the ideal solution. Ideally, wind ties would be sewn on to the bottom of the curtains. The retrofit solution should only be used when no other options are available. A local awning manufacturer may be able to assist in sewing the wind tie to your product. Goffs does not warranty the retrofit wind ties.